



Vertical blinds models K 01, K 01 Lux, EOS, Vogue




In order for the textile strips to be able to rotate freely, they need to have free space around them. That space has the following dimensions:


- 5 cm for fabric 89 mm;
- 7 cm for fabric 127 mm.



Attach the plate with a screw to the ceiling (for ceiling installation) or...



... „Г“-shaped plate with a bracket for the wall (for wall installation). Install the plates on every 1.5 cm along the width of the blinds.




Then clutch the profile and the bracket together but first infix the back part and then press the front part from the bottom.




By pulling the chain rotate the hooks so that they are in the same position.



Attach the textile strips to the hooks and carefully make sure that the hems of the fabric are on the same side.



Infix the weights in the pockets in the bottom end of the textile strips as the “ears” have to be on top.



Link the weights through the rope with the pinches – in this way you synchronize the rotation of the strips.



**System monocomando:** Attach the hooks to the ear of the worm gear of the PVC stick..  
 (only for model aluminum track system Vogue )