


model insect sreen with hinges



Installation guide



Insect screens with hinges



Hinges have two parts, one of which is installed on the arms of the screen, and the other one – on the joinery. Decide where to place the hinges depending on the side on which you want the screen to open. Attach each hinge to the frame with two screws.

The pin also consists of two parts, one of which is installed on the frame of the screen and the other one – on the joinery. Attach the pin to the frame with two screws. Place the closing handle. The handle should be placed opposite the pin.



Mark the spots on the parts of the hinges for installation on the joinery. Install each part with two screws.

Attach the screen to the hinges.

Install the counter of the pin on the joinery with two screws. Attention – there is always a slight sag of the screen in an open position. To avoid it in closed position you have to install the counter of the pin to a level where the screen stands horizontal when clicking the screen in closed position. Simply said - when closing the screen you have to slightly lift it to go into the pin.