



www.kamax.bg  
 online.kamax.bg




## Installation guide



### Door insect screens Standard



Hinges have two parts, one of which is installed on the arms of the screen, and the other one – on the joinery. Decide where to place the hinges depending on the side on which you want the screen to open. Install each hinge to the frame with two screws. Mark the spots on the parts of the hinges for installation on the joinery. Attach the parts with two screws each. Regulate the tightening of the spring of the hinges. Open and close the door several times to check it.




The magnet also consists of two parts, one of which should be installed on the frame of the screen, and the other one – on the joinery. Attach the magnet to the frame with two screws. Install the closing handle outside on the suitable place. It is usually positioned in the middle. Attach the screen to the hinges. Install the counter of the magnet on the joinery with two screws.

### Door insect screens Lux



Hinges have two parts, one of which is installed on the arms of the screen, and the other one – on the joinery. Decide where to place the hinges depending on the side on which you want the screen to open. Install each hinge to the frame with two screws. Mark the spots on the parts of the hinges for installation on the joinery. Attach the parts with two screws each. Regulate the tightening of the spring of the hinges. Open and close the door several times to check it.




The magnet also consists of two parts, one of which should be installed on the frame of the screen, and the other one – on the joinery. Attach the magnet to the frame with two screws. Install the closing handle outside on the suitable place. It is usually positioned in the middle. Attach the screen to the hinges. Install the counter of the magnet on the joinery with two screws.

### Door insect screens Prestige



The screen is installed in a frame.



Place on the joinery, level the frame and install with suitable screws.